

OPERATION OF THE WASTE CHUTE (BOBBY BOX)



Hold the transponder (chip) in front of the transponder panel. The green indicator lights up and the compartments are unlocked.



Now you can open one of the two compartments and dispose of your waste.
The selected volume is shown on the display, e.g. 20 l.



After closing the shaft, the system locks automatically.
You do not need to do anything else.

Special operating conditions

Additional information can be displayed on the screen:

Voll: Container is full

FE. 1: no container in the box

GPRS: Data transfer: Please wait a moment!




Tip:

Use the smallest chute that your waste fits into. This way, you will not be charged unnecessary costs.

Notice:

Each time the chutes are opened, a record is made for subsequent operating cost billing – regardless of whether you actually dispose of waste or not!



Display panel:

green - AUF
yellow - CHIP
red

Shafts unlocked
Chip not authorised
error message



JETZT AUCH ONLINE

SAVING MONEY AND LOOKING AFTER THE ENVIRONMENT, MADE EASY:

- Do not place any waste near the refuse lock
- Do not place any residual waste in recyclables
- Fold up larger packaging
- Make use of reusable packaging
- Use a shopping basket instead of plastic bags
- Make larger boxes smaller

Why do we need a refuse lock?

Waste disposal will be allocated by apartment and therefore you will only pay for what you dispose of (a minimum quantity will apply).

When will my waste deposit be registered?

As soon as you have opened the deposit chute.

How much waste can I deposit?

The full capacity of the deposit chute will always be used, so you should take full advantage of the storage.

What should I do if my waste does not fit in the chute?

Our recommendation is to use bin bags that make the most of the dimensions of the chute. Bulky objects should be placed in bulky waste or reduced in size before being disposed of.

What happens if the waste container in the refuse lock is full?

A red continuous light will appear (after you have turned it on). Until the container is emptied, no more waste can be deposited.

I have lost my transponder?

Please contact your housing administration immediately, so that nobody is able to deposit any waste on your behalf.

I have no waste to deposit?

Every household has waste that must be disposed of as per local waste management.

WHY DO I NEED TO PAY THE COSTS FOR THE WASTE I PRODUCE?

Residual waste: It is expensive to dispose of residual waste and waste tax would be likely to increase.

Recyclables: It is free to dispose of plastic and metal packaging (e. g. drink bottles, yoghurt pots, tins ...), paper and glass. This is because the disposal costs for such products are already included in the sales price and therefore you already pay this!

Our aim: Save money!

How? Reducing the amount of residual waste by correctly separating our waste!



Please note: Dispose of all waste that is not collected in the containers for residual waste in the recyclables container that has been provided for this purpose (yellow/orange bins, yellow binbags, paper containers, glass containers, old clothes collection, etc...). **Please note the guidelines on how to separate your waste.**

Please note: If residual waste is wrongly put into the recyclables container, the whole container will be disposed of at the price of residual waste. That means unnecessary higher costs for everybody!



JETZT AUCH ONLINE

ABFALLKONZEPTE | ALLES AUS EINER HAND